

Starting The Firing

Either



To run the program last viewed or used

Or



To display program number



To select the required program



To Store the new program number




To Run the selected program

When the program starts the program number will be displayed for a short time and then the program will run.

Function
Delay

Display


Description



Remaining Delay Time

Delay (Flashing)

Ramp



Current Temperature

Up Ramp (Flashing)

Dwell



Current Temperature

Dwell (Flashing)

Stopping the Firing manually

If the controller is running then one of the mimic lights will be flashing.



To stop the firing press the Start / Stop key once.

During the Firing

Pause



Press Once to Pause, Press Again to Continue

— — — — — Display will flash when paused

This function can be disabled,
A timed over-ride is also applied (15 minutes default)
See installation Manual – Configuration to change if required.

Info Key



Press to scroll through various parameters.

- Pn* Program number currently running.
- E* Energy used so far during Firing in KwH.
- SP* The Current Setpoint value.
- rd* Remaining time in Dwell. (Dwell segment only)

Segment Advance



The controller will move to the next step in the program.

Event Override



This key over rides the event relay state.
The 'Event' Lamp shows the current state.

If the program moves to a new segment the value set in the program will be applied.

Slow Firing



A Flashing indicator that tells the user that the kiln has not kept up with the program.

(With programs that have previously worked this may indicate faulty elements .

Keypad Lock (Secret)

This key locks or unlocks the rest of the keys.

Press and hold for approximately a second.

The Lamp is lit when locked.

Advanced

Modifying a running program

You may modify a running program. The following points should be observed;-

- Make sure you are modifying the correct segment.
- If you change a dwell time you will re-start that Dwell from the new value.
- If you change an Up Ramp such that the new end temperature is lower than the current temperature then the ramp will change direction. (Similarly for the opposite case)
- If you change a Dwell setpoint when you are in the Dwell the controller will attempt to change as rapidly as possible. You may get Over or Undershoot in these conditions.

When modifying a running program.

- The segment number is the one you are changing.
- The static mimic lamp is the value you are viewing.
- The flashing mimic lamp indicates only if the controller is on a Ramp or a Dwell.

To accept the changes you have made you must press the Start / Stop key once only. (If you press it twice you will terminate the firing!)

Event Programming

The Event output is programmed as either On or Off in each part of every program segment. If a segment is programmed with E = r- then the relay will be turned On at the start of the ramp and Turned Off at the start of the Dwell.


- When the controller is first powered the event will be Off.
- When a program is run the event relay will respond to the entered values for each segment.
- The user may over ride the state at any time by pressing the "Event" key. (The 'event' lamp will show the current state)
- Whenever the power is turned off the current state of the event relay is stored, and restored upon return of power.
- When the program Ends the Event relay is left in its last state.

Whilst switching at a specific temperature is not directly supported, this may easily be achieved by adding extra segments.

Page 9




1st Dwell Time



- Pass (=0)
- or
- 0.01 to 99.59 (HH.mm)
- or
- Hold (=Max)



1st Event sequence



Event version only.

The Relay will be on in;-

- -- = Event Off
- or
- rd = Ramp & Dwell
- or
- -d = Dwell only
- or
- r- = Ramp only

For more detailed information on setting up events see later in this manual

Continue entering segment information until the firing profile has been completed

End


Mark the end of a firing sequence (This example has four segments in the program and so five is marked as the end)

Action



Ramp Rate

Display



Values



- Press and hold until;-
- End

Exit Program mode



Caution

If you press this twice you will exit program mode and then run the program

Delay


Pick the program number you wish to use and set the initial delay prior to the firing.

Action



Program No?

Display




Values



- 1 to 10
(1 only on SP model
1-4 on Pottery model)



Delay



- Pass (=0)
- or
- 0.01 to 99.59
(HH.MM)

Segments


Enter the values for your firing as a sequence of segments
(See the attached sample form.)

Action



1st Ramp Rate

Display




Values



- 1 to 999 °C/Hour *
- or
- Full (=Max)
- * (0.01 to 99.59 HH.MM
in time mode)



1st Temperature



- 1 to Setpoint limit
- or
- End (=0)

eg. To have an initial Ramp to 600°C at 100°C per Hour, with a damper opening at the start, and closing at 300°C;-

Enter

Ramp 1 @ 100°C to 300°C, Dwell 1 = Pass, & Ramp event On
Ramp 2 @ 100°C to 600°C, Dwell 2 = as req'd, Ramp event Off

Info Key



This key serves various purposes;-

- **Whilst entering a program**

Whilst pressed the key will show the program number you are setting.

- **During a Firing**

Scrolls through various parameters

- P_n Program number currently running
- E Energy used so far during Firing in KWh
- SP The Current Setpoint value
- rd Remaining time in Dwell (Dwell segment only)

- **Firing complete**

- E Energy used in KWh
This value is stored until a new firing is started

- **Parameter Setting**

See the Installation manual

Kiln Energy

The display of energy used is an estimated usage based upon the value entered in configuration for the rating of your kiln. Since ageing of elements will affect this you should use this as a comparative value rather than an absolute measure.

Power Failure

If the power fails during a firing the controller will check to see the temperature upon restoration of power. If this has not changed by more than 100°C / 180°F the firing will continue. If the change is greater than 100°C the controller will show. **PF**

3 Zone Control

The “3 Zone” controller may be used as a three or two zone control. Whichever is to be used the controller may be configured for two methods of control which we define as Absolute or Differential.

Comparison

	Diff (Default)	Abs
Best Uniformity	Yes - If main zone is slowest	No
Fastest firing	No – Restricted by slowest zone	Yes
Simple to set up	Interaction between zones may be a problem	Yes

Differential

The main zone is controlled directly by the program. The other zone(s) will attempt to follow what the main zone achieves. (This is the equivalent of having differential controllers and back-to-back thermocouples for the slave zones)

With this configuration it is normal to make the main zone the slowest in the kiln. The controller will then provide the best uniformity by slowing down the faster zones to match the slowest.

Absolute

All zones follow the program profile directly. If they are not able to achieve the set rates then they will only achieve what each zone is inherently capable off.

Hardware Definition Code

The 3 Zone controller has five possible outputs (Zone 1, Zone 2, Zone 3, Alarm, Event.) However only four outputs may be used. The user must choose which are required and set the hardware definition code to define this choice. See the installation manual for details of setting the Hardware definition code.

Program Entry



To set a program you should first check that a program is not running.

If there are flashing lamps on the mimic Press the Stop / Start key once to Stop

The key functions whilst entering a program are:-



Move forward and back through program segments



To change values for each segment




To Exit program mode and save the changes




To show the program number you are setting.





The programming form provides a convenient way of ensuring you have all the information required to hand. It also provides a record of what you have programmed into the controller.



Switch On

The controller power switch is located below the unit. When the unit is first switched on, all of the segments on the display and all of the indicators are illuminated, as a lamp test. The displays then show information, which defines the particular instrument you have, for 3 seconds.



-  Thermocouple type
-  Software revision
-  Model Type
(See specifications)
-  Temperature units

After 3 seconds the display will show the current kiln temperature. You may then Run or Amend a program.



Important

If you phone for technical support we will need to know the information displayed above.


Switch Off

It is recommended that you ensure you have stopped the program (No mimic lights will be flashing) before switching off. Note that if you switch off whilst the controller is running a program, the controller may start automatically when you switch on again.

Mounting

The controller should be mounted on a vertical surface away from heat. In particular ensure that it is not exposed to direct heat from an open kiln door or lid.

Mounting is via a removable bracket. Slide the bracket from the rear of the unit and fix vertically, using No 8 wood screws.



Connections



It is vital that all electrical installation is carried out in a professional manner.

In most instances the controller will either have a plug, which matches your kiln, or will be connected by your supplier.






If a plug is fitted check that the pin layout of the plug and socket are an exact match before plugging in.

We do not recommend DIY installation of this product. Wiring is best carried out by a kiln builder or supplier who will have experience of the product and access to all installation information.

For further information contact your kiln supplier.

Configuration


Changing the values in the list should only be undertaken by an experienced operator or engineer.

- With the instrument switched Off
- Press and hold the  key whilst turning on the power.
- Wait until the first parameter is shown
 - Use the  key to move through the list
 - Use the   keys to change parameters
- Press the  key to exit configuration and use the controller

	Display	Parameters
User Level		
Alarm Type	AL	OFF or bAnd or tr IP
Alarm Temp	AL	NB The band alarm will not trigger during a Ramp if a ramp rate of Full is selected
Kiln Rating (Kw)	Kr	0 (Default) to 99.9 Kw
Trip Temp (Option Board)	OT	This value is above the highest point in the program Default = 50°C
Engineer Level	EL	You are blocked at this point

User Controls

General View



The controller is a highly adaptable unit which allows the user much greater flexibility in program entry than has previously been possible.

The user may freely create programs with segments consisting of either Up or Down Ramps and Dwells. Depending upon the model you may create up to ten programs each containing up to sixteen segments, where a segment is one ramp and one Dwell.

Additionally you can

- Create indefinite Dwells for a holding firing.
- Create your program using either ramp rates or elapsed times.
- With the Event version trigger events at each segment,

Contents

User Controls _____	2	
• General View		2
• Switch On		3
• Switch Off		3
Program Entry _____	4	
• Delay		5
• Segments		5
• Event		6
• End		6
• Exit Program Entry		6
Starting the Firing _____	7	
Stopping the Firing Manually _____	7	
During the firing _____	8	
• Pause		8
• Info Key		8
• Segment Advance		8
• Event Override		8
Keypad Lock _____	8	
Advanced _____	9	
• Modifying a running program		9
• Event Programming		9
• The Info Key		10
• 3 Zone Control (Option)		11

About this Manual

These instructions take you through the process step by step assuming you are using the controller for the first time.

Basic operations are shown first and more complex operations are shown at the end

Installation

A separate manual is available showing how to connect the unit and configure for particular applications. If you purchase this unit from a kiln supplier they will normally have done this for you.

Title	Description	English	German
Slow Start	Kiln rises too slowly at start of firing ie T/C not in, or short cct, Kiln failed	Err1	F1
Band Alarm			
Over Temp			
T/C High	T/C input above the T/C max	Open	F3
T/C Low	T/C input below the T/C Min	Fail	F4
Finish	Program completed	End	Ende

Slow Start

When program is started, controller looks for a change in setpoint of 50°C. If the process has not changed by >10°C at this point then an error is raised. This function can be disabled by setting err1 to off.

Band Alarm

The measured temperature is differs from the setpoint by more than the value set in Alarm Temperature.

Over Temp**T/C High**

This signals that the controller has seen a value above the maximum for the thermocouple. This will normally be caused by open circuit thermocouple wiring.

T/C Low

This signals that the controller has seen a value below the minimum for the thermocouple. This will normally be caused by reverse connected thermocouple wiring.

Error 5 Trip Alarm only

The process temperature has exceeded the highest setpoint by the amount set in Alarm Temperature. 20°C default

Specifications

All models

Supply

207-265 VAC or
104 -127 VAC (To Order)
50/60Hz - 6VA max

Environment

0 to 40°C operating
-10 to +50 Storage

Outputs

Standard - (Single Pole N.O.)

- 230V 1A max
- Control and Alarm outputs can switch 230VAC 30A Max when wired as shown (See installation notes)

Option

- SSR > 5V @ 40mA

Connections

2 part removable connectors
Max wire Capacity - 2.5mm²

Thermocouple

Selectable R, S, K, N
Range
R/S -20 to 1600 °C °F
K/N 0 to 1300 °C °F
Resolution 1 Degree

Accuracy

+/- 0.1% FSD +/-1digit

Control

Adaptive PID

Enclosure

Dimensions
W - 120 x H - 190 x D - 78 mm

Fixing

108mm on centre line

Material ABS

Alternate inserts allow Single or
Dual cable entry holes

Trip

Accuracy +/- 10°C



User Instructions

ST 3300 Temperature Programmer



Models

	3300-1	3300-2	3300-3	3300-4	3300-5
Display Ident	1	2	3	4	5
No of programs	1	10	10	10	10
No of segments	2	4	16	16	16
Control Output	1	1	1	1	3
Alarm/Gas Output	1	1	1	1	1
Event Output				1	1

